

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC4880X**

Est. Installation Time: **less than 10 min.**

Cadillac XLR (2004-09), Chevrolet Corvette (2005-14)

OEM No. 15848592

The cabin air filter is located under the hood, under the passenger side windshield wiper.

1. Open the hood.
2. Locate the cabin filter housing cover, under the hood, under the passenger-side-wiper – Fig. 1
3. The filter-housing cover is secured with 3 latches on the upper edge of the cover. Unlatch all 3, and flip the cover down.
4. Pull out the old filter - Fig. 2, and clean the housing.
5. Insert the new filter into the housing, while the air-flow arrows are pointing up.
6. Close the housing cover and lock the 3 latches.



Figure 1



Figure 2