

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC4902X**

Est. Installation Time: **less than 30 min.**

Chevrolet Optra (2004-07), Suzuki Forenza, Reno (2004-08) OEM No. 95860-85Z00

The cabin air filter is located below the glove compartment.

1. Locate the cabin filter housing cover, below the glove compartment
2. Remove the 4 screws securing the filter housing access cover.
3. Pull out the old filter (we recommend to cover the floor)
4. Clean the housing
5. Inset the new filter, with the tab facing down
6. Install the housing cover and secure it with the 4 screws

