

# CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC5389X**

Est. Installation Time: **less than 10 min.**

Ford Freestar (2004-07), Windstar (1999-03), Mercury Monterey (2004-07) Ford XF2H-19N619-AC

1. The cabin air filter is located under the cowl on the passenger side
2. Open the hood
3. Open housing by pressing the clip on the left side to the right and pulling the cover out.
4. Using your two pointer fingers, hold the old filter from both sides, raise it up to clear it from the far edge and pull it out
5. Hold the new filter with the edge of the foam seal around the filter facing down.
6. Insert the new filter into the housing frame and push it down
7. Close the hood

