

# CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC5471X**

Est. Installation Time: **less than 15 min.**

Buick Rendezvous (2002-07) Terraza (05-07), Chevrolet Uplander (06-09), Venture (01-05) , Oldsmobile Silhouette, (01-04) Pontiac Aztek, (01-05) Montana (06-09) Oem No. 10322538

1. The cabin air filter located inside the glove box behind the access door (2 filters)
2. Open the glove box. In the back of the glove box you will see the plastic cover with. Pull the tab at the lower edge, up and toward you.
3. Once open you will see the access door to the filter housing – Fig. 1
4. Unlatch the access door pushing the tab on the left side to the right
5. Pull the 1<sup>st</sup> filter out. Hold the 2<sup>nd</sup> filter on the left side, slid it to the right and pull it out. Clean the filter housing
6. Make sure the foam frame around the new filters is facing down (sliding down from left to the right). Insert the 1<sup>st</sup> new filter and slid it all the way to the left.. Insert the 2<sup>nd</sup> new filter
7. Close the filter access door and make sure it is latched
8. Install the plastic cover of the back of the glove box and close the box

