

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC5662**

Est. Installation Time: **less than 20 min.**

Hyundai Elantra (01-06), Entourage (07-10), Tiburon (03-08), Kia Sedona (05-12) OEM No. 97133-2D000

The cabin air filter is located behind the glove compartment

1. Using a Philips screwdriver, remove the 2 screws at the bottom of the bottom of the glove box
2. Open the glove compartment and remove the 4 screws across the top of the glove compartment (2 in the center are securing the latch) – Fig. 1
3. Slowly pull out the glove box assembly. Once you see the wires and light module

WARNING: DO NOT LET THE GLOVE COMPARTMENT HANG BY THE AIR BAG MODULE WIRES. DO NOT PULL ON THE AIR BAG MODULE WIRES. DO NOT DISCONNECT THE AIR BAG MODULE WIRES.

4. Disconnect the wire connector from the glove compartment light – Fig. 2
5. Remove the glove compartment assembly from the dashboard and set aside.
6. Unclip the latchets from the filter housing access door. Push up and pull out on the bottom edge of the cover and pull it out – Fig. 3
7. Pull out the old filter and clean the housing
8. Insert the new filter and close the housing cover. Secure the cover with the metal latchets – Fig. 4
9. Connect the light wires . Follow the reverse steps to install the glove box assembly and secure it with the 6 screws.



Figure 1



Figure 2



Figure 4



Figure 3

This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.