

# CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC5675AHX** Est. Installation Time: **less than 15 min.**

Hyundai Santa Fe (01-06), Sonata (99-05), XG300 (01), XG350 (02-05)

1. Open glove box and remove glove box clips to access filter.



2. Remove Filter Cover.



3. Replace filter and reverse steps 2-1.

This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.