

## **INSTALLATION TIP**

## FIRST-TIME INSTALLATION OF CABIN AIR FILTER PC6205x

Access Door - OE#20968419

Cabin Air Filter - OE#20958479

APPLICATIONS		
YEAR	MODEL	ENGINE
2008 - 2011	Buick Enclave	3.6L
2009 - 2011	Chevrolet Traverse	3.6L
2007 - 2011	GMC Acadia	3.6L
2007 - 2010	Saturn Outlook	3.6L

The applications listed above do not come with a factory installed cabin air filter. However, it can be retrofitted. It requires cutting the opening of the access panel to accept the filter. An access door is then included which conceals the opening.

- 1. Remove the instrument panel compartment.
- 2. Cut out the molded access panel on the HVAC module using the appropriate tool.
- 3. File down any rough edges to ensure a proper fit.
- 4. Install the filter into the access door.
- Slide the access door into the HVAC module and press into position ensuring the four locking tabs are fully seated.
- 6. Remove any debris.
- 7. Install the instrument panel compartment





