

# CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC6286X**

Est. Installation Time: **less than 15 mins**

**Ford OE: DG9Z-19N619-A**

The Cabin air filter is located behind the glove compartment

- Open the glove box and remove the piece of trim on the right side
- Remove the trim above the glove box by unhooking it starting with the right side
- Close the glove box
- Using a 7mm wrench remove the two bolts that secure the bottom of the glove box assembly
- Using a 7mm wrench remove the two bolts that secure the top of the glove box assembly
- Open the glove box
- Pull out on the glove box assembly to unclip it from the vehicle
- Tilt the glove box assembly and set it on its side to expose the connector on the back
- Remove the two Phillips screws from the sides of the filter cover to open it.
- Remove the old filter from the housing, taking note the air flow arrow indicator on the side of the old filter
- Install your new filter into the housing
- Replace the rest of the glove box assembly by reversing the removal procedure

This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.