## **CABIN AIR FILTER – INSTALLATION INSTRUCTIONS**

Part No.: **PC9373X** Est. Installation Time: **less than 20 mins** 

## Mercedes Benz OE: A 172 835 00 47, A 171 830 04 18

- Unbolt the kick panel which is located under the glove box and remove all the screws
- Pull back the passenger side floor carpeting
- Unplug on the interior kick panel plug on the underside on the panel
- Disengage the retaining bracket and lift out the kick panel
- Remove the white plastic cover on the left side
- Unlatch the cabin filter access door
- Remove the old filter from assembly, taking note the air flow arrow indicator on the side of the old filter
- Insert new filter into the assembly, making sure the air flow direction is correct according to the arrow indicator
- Replace the rest of the assembly by reversing the removal procedure