

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Item No.: **PC9376X**

Est. Installation Time: **less than 15 min.**

Mercedes Benz OE: A 166 830 03 18, A166 830 02 18

1. Remove the three screws that hold the bottom panel to the bottom of the glove box and pull away the panel



2. Open the glove box, remove the cover panel from the right side, and remove the screw at the bottom right of the glove box assembly.



3. Remove the three screws from the top of the glove box.
4. Pull out the glovebox slightly to remove a light connector that is under a bit of fabric and then rest the glovebox assembly against the center console as to not stress the connected wires.
5. Slide the cover lock to the left to remove and remove it.
6. Remove the filters and replace
7. Reverse steps 5-1.



This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.