


# CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Est. Installation Time: less than 15 min.

The Cabin Air Filter is located behind the glove box.

1. Locate the kick panel, unscrew the 5 bolts, and remove the kick panel.



2. Remove the filter housing cover,



3. Remove and replace cabin air filter with arrow point the same direction.
4. Reverse steps 2-1.

This is only a guide and may not be for exact model. See Owner's manual and/or local Technician for exact instructions for the particular model.