

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS


Part No.: PC4482HX

Est. Installation Time: less than 20 min.

Mazda OEM No. BP4K-61-J6X, CC29-61-J6X, CC64-61-J6X, CE49-61-J6X

The cabin air filter is located behind the glove compartment.

1. Push inward both sides of the glove box to disengage the stoppers on both sides
2. Locate the cabin filter plastic cover and unlock it
3. Pull out the old filter and clean the housing
4. Insert the new filter in the housing with the air flow arrow pointing down
5. Install and secure the filter housing cover back
6. Push inward both sides of the glove box and raise it to re-engage the stoppers.
7. Close glove compartment



G00216251

