


CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Est. Installation Time: **less than 15 min.**


The Cabin Air Filter is located behind the glove box.

1. The cabin air filter is located behind the glove compartment
2. Open the glove compartment and remove the screws that secure the compartment to the dashboard
3. Remove the clip on the right-hand side of the glove compartment.
4. Pull the glove compartment down and **disconnect the glove box light connector** (some applications).
5. Detach the glove compartment and put it aside.
6. Locate the cabin air filter cover. Unhook the hooks of the cover and remove the cover. See



G00280554

7. Removing Cabin Air Filter Cover. Draw out the cabin air filter element



1. Air Filter Element

G00280555

8. Clean the filter housing of any remaining
9. Insert the NEW cabin air filter element. The arrow mark on the filter must point down.
10. Reinstall the cabin air filter cover. Connect the connector and reinstall the glove box. Close the glove box.

This is only a guide and may not be for exact model. See Owner's manual and/or local Technician for exact instructions for the particular model.