


CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Est. Installation Time: **less than 15 min.**

The Cabin Air Filter is located behind the glove box.

1. Cabin air filter located on the passenger side under the right side of the instrument panel in the HVAC housing (some models, cabin air filter is available as an optional dealer-installed kit)
2. Locate the cabin air filter housing cover – see below.
3. Remove the screws retaining the filter housing cover.
4. Remove the housing cover.
5. Hold the tab at the center of the old filter and pull it down.
6. Insert the new filter, while the tab in the center is pointing down.
7. Close and secure the filter housing cover with the screws.



This is only a guide and may not be for exact model. See Owner's manual and/or local Technician for exact instructions for the particular model.