

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS


Part No.: PC5448X

Est. Installation Time: less than 15 mins

GM OE: 25654414

The Cabin air filter is located in front of the windshield under the filter access cover on the passenger side of the vehicle

- Open the hood
- Open housing by unsnapping the filter cover.
- Locate the filter retainer latch located on the left side of the filter housing.
- Push the retaining latch toward the windshield side and pull the old filter up and toward the front of the vehicle to remove.
- Insert the new filter into the frame. There are two cuts in the right and left sidewall of the filter so that the smaller side can be folded “down and under” to seat properly in the housing.
- Insert the filter and frame into the housing
- Close filter housing cover. Make sure the cover is latched and secure, so water do not enter the housing.
- Close the hood.



This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.