

# CABIN AIR FILTER – INSTALLATION INSTRUCTIONS


Part No.: **PC5477X**

Est. Installation Time: **less than 10 min.**

**OE PN: 25906375, 25689297**

The cabin air filter is located under the cowl on the passenger side

1. Open the hood
2. Open housing by unsnapping the filter cover.
3. Locate the filter retainer latch located on the left side of the filter housing.
4. Push the retaining latch toward the windshield side and pull the old filter up and toward the front of the vehicle to remove.
5. Insert the new filter into the frame. There are two cuts in the right and left sidewall of the filter so that the smaller side can be folded “down and under” to seat properly in the housing.
6. Insert the filter and frame into the housing
7. Close filter housing cover. Make sure the cover is latched and secure so water do not enter the housing.
8. Close the hood.



This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.