

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: PC5478X



Est. Installation Time: less than 15 mins

Ford OE: YL8Z-19N619-AA: Mazda OE: ZZCA-61-J6X

The Cabin air filter is located in front of the windshield under the cowl grille

- Locate and remove the two screws holding up the plastic cover in front of the filter access door
- Turn on the ignition switch.
- Turn on the wiper switch to low speed. When the wipers are in the vertical position, quickly switch off the ignition
- With the hood closed, remove the four Phillips head screws at the base of the windshield on the right side
- Open the hood and remove the four Phillips head plastic fasteners along the forward edge of the access panel
- Disengage the clips and remove the cabin air filter box cover by tilting the front edge up first, then pulling it forward
- Remove the old filter

Access panel



This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.