
CABIN AIR FILTER - INSTALLATION INSTRUCTIONS

Part No.: **PC5621X** Est. Installation Time: **less than 30 min.**

The cabin air filter is located behind the instrument panel on the driver side, next to the accelerator pedal

- 1. Make sure the ignition is turned off.
- 2. Remove 3 retaining plastic screws securing the carpet.
- 3. Fold carpet back to expose the filter housing cover.
- 4. Remove the nuts securing the filter housing cover
- Remove filter by pulling it out in front of the accelerator pedal and behind the brake pedal.
- 6. Install air filter by compressing it slightly and inserting it behind the brake pedal. Make sure the air-flow arrow is pointing to the rear of the vehicle.
- 7. Clamp the cover in place at the rear edge and secure it with the nut.
- 8. Fold back the carpet. Install the plastic 3 screws



This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.