


CABIN AIR FILTER – INSTALLATION INSTRUCTIONS


Est. Installation Time: **less than 15 min.**

The Cabin air filter is located behind the glove box


1. Open the glove box. Lower the glove box down completely by removing the travel stops located on each side of the glove box.




2. Remove the glove box(A) from the lift(B).



3. Remove the filter cover (A) push the tabs in and pull. Remove the old cabin air filter, taking note the air flow arrow indicator direction on the side of the old filter.



4. Insert the new filter (B) into the housing, making sure the air flow direction is correct according to the arrow indicator.



5. Complete the install by reversing the removal procedure.

This is only a guide and may not be for exact model. See Owner's manual and/or local technician for exact instructions for the particular model.