
CABIN AIR FILTER - INSTALLATION INSTRUCTIONS

Est. Installation Time: less than 15 min.

The Cabin air filter is located behind the glove compartment

- 1. Open the glove box
- 2. Remove the 9 screws securing the glove box



- 3. Pull the glove box out. There are two clips on the right side that you need to unclip.
- 4. Locate the filter housing cover
- 5. Remove the filter housing cover by unclipping the two latchets at the bottom edge
- 6. Pull the old filter out from the housing and clean the housing



- 7. Insert the new filter into the housing while the air-flow arrows pointing down.
- 8. Clip the cover back into place.
- 9. Revers steps 3 & 2 to install the glove box



This is only a guide and may not be for exact model. See Owner's manual and/or local technician for exact instructions for the particular model.