

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC5876X**

Est. Installation Time: **less than 15 mins**

Ford OE: 7T4Z-19N619-B; Mazda OE: L2Y6-61-P11

The Cabin air filter is located behind the glove compartment

- Open the glove box
- Release the dampener cord
- Push in on both sides of the glove compartment until the glove compartment comes forward and lift completely off (Fig 1)
- Remove the glove compartment assembly to access the blower assembly to the lower left
- Remove the filter access door by pushing the clips inwards
- Remove the old cabin air filter, taking note the air flow arrow indicator on the side of the old filter (Fig 2)
- Insert the new filter into the assembly, making sure the air flow direction is correct according to the arrow indicator
- Replace the rest of the glove box assembly by reversing the removal procedure




Figure 1



Figure 2

This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.