CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: PC6098HX Est. Installation Time: less than 15 mins

Mazda OE: BBM4-61-J6X

The Cabin air filter is located under the dash on the passenger side of the vehicle

- Pull out on the passenger side kick panel and pull back to remove it.
- Unclip the two tabs to remove the panel below the glove compartment
- Remove the two screws that secure the bottom of the cover to the housing
- Unlatch the tab at the top to remove cover from the housing.
- Remove the wire connect from the cover so you can set it aside.
- Remove the two cabin air filters from the housing, clean inside the housing, and replace the two filters.
- Reverse steps 5-1.



This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.