

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC99237X**

Est. Installation Time: **less than 15 mins**

The Cabin air filter is located behind the glove compartment

- Locate the damper's arm at the outside right of the glove box
- Detach it simply by pulling the damper's arm to the right
- Allow the glove box to swing down
- Unlatch filter cover by squeezing the right-side clip together and pull the filter cover out
- Disengage the claw and 2 guides to remove the cover as shown in the illustration (Fig 1)
- Remove the old filter from assembly, taking note the air flow arrow indicator on the side of the old filter (Fig 2)
- Insert the new filter into the assembly, making sure the air flow direction is correct according to the arrow indicator
- Replace the rest of the glove box assembly by reversing the removal procedure

This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC99237X**

Est. Installation Time: **less than 15 mins**




Figure 1




Figure 2



Remove in this Direction

This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.