

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC99474X** Est. Installation Time: **less than 15 mins**

Lexus OE: 87139-50110

The Cabin air filter is located behind the glove compartment

- Open the glove box
- Detach the claw and guide and pull the glove compartment door in the direction indicated by the arrow shown in the illustration to remove it (Fig 1)
- Detach the claw and guide to remove the lower instrument cover (Fig 2)
- Remove the cabin filter access door by pinching and rotating the claw in the direction indicated by the arrow shown in the illustration to detach it and slide the cover to the right (Fig 3)
- Remove the old filter from the air filter case, taking note the air flow arrow indicator on the side of the old filter (Fig 4)
- Insert new filter into the air filter case, making sure the air flow direction is correct according to the arrow indicator
- Replace the rest of the glove box assembly by reversing the removal procedure




Fig 1




Fig 2




Fig 3




Fig 4

This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.