

CABIN AIR FILTER – INSTALLATION INSTRUCTIONS

Part No.: **PC99492X**

Est. Installation Time: **less than 15 min**

Alfa Romeo OE: 6832 0112AA

The Cabin air filter is located under the dashboard and can be accessed from the front passenger floorboard

- Disconnect and isolate the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), disconnect the IBS connector first before disconnecting the negative battery cable
- Remove the right hush panel
- Using a suitable tool, release the right front floor air outlet push pin (1a) (Fig 1)
- Remove the left/right front floor air outlet (2a) by releasing it from the HVAC housing (2b) (Fig 1)
- Disconnect the wiring harness (1a) from the retainers (1b). (Fig 2)
- Release the retainer (2a) and remove the cover (2b) for the cabin air filter. (Fig 2)
- Remove the cabin air filter (1) from HVAC housing by pulling the filter element straight out of the housing. (Fig 3)



Fig 1




Fig 2




Fig 3

This is only a guide and may not be for exact model. See Owner's manual and/or local mechanic for exact instructions for the particular model.